



MEASUREMENT LIST

Brand: PRINTER ACTIVE WEAR

Style: **2265011 Surf LS RSX**

	XS	S	M	L	XL	XXL	3XL	4XL	5XL
body lenght CB	68	70	72	74	76	78	80	82	84
1/2 chest	47	50	53	56	60	64	68	72	76
Sleevelenght	63,5	65	66,5	68	69,5	71	72,5	74	75,5

All measurements are indicative with minimum tolerance of 1 cm