



MEASUREMENT LIST

Brand: PRINTER ACTIVE WEAR

Style: **2265019 Surf pro RSX**

	XS	S	M	L	XL	XXL	3XL	4XL	5XL
body lenght CB		70	72	74	76	78	80	82	84
1/2 chest		50	53	56	60	64	68	72	76
Sleevelenght		19	20	21	22	23	24	25	26

All measurements are indicative with minimum tolerance of 1 cm