


Printer
ACTIVE WEAR

SIZE CHART



Brand: PRINTER ACTIVE WEAR

Style: 2261511 SWITCH LADY

	XS	S	M	L	XL	XXL	3XL
A) body length from shoulder point	63	65	67	69	71	73	75
B) 1/2 chest width	43	46	49	52	56	60	64
c) sleeve length	62	63	64	65	66	67	68

All measurements are indicative with minimum tolerance of 1 cm

